

Amendment

Amendment to XDS5/10 and 35i Silencer Kit (A505-97-880 Issue C)

The following section has been updated:

3 INSTALLATION

3.2 Install the XDS silencer

Ensure the pump is switched off before fitting.

1. Clean the face of the pump exhaust with a lint free cloth.
2. Place the centring ring (Figure 1, item 5) in the end of the NW25 flange and seat the silencer in the pump.

Below is an additional comment that needs to be added to the instruction manual

Note: Exhaust hole should be pointed downward and away from the operator to avoid any foreign body, process material or condensate that may be evacuated on start up.



This page has been intentionally left blank.